

## MiniPak'r Troubleshooting Guide

Display Code	ERROR	ACTION
E 1	Cover Open	Make sure covers are closed.
E 2	Jam/End of roll	In case of jam, open Belt Cover & remove jammed film carefully.
E 3	Temp. too high	Contact Pack4Shp or Pregis Help at 866-374-7877
E 4	Temp. too low	Contact Pack4Shp or Pregis Help at 866-374-7877
E 5	Temp not rising	Contact Pack4Shp or Pregis Help at 866-374-7877
E 6	No roll detected	Press STOP/RESET. This may clear the error. If not, display will show "STY" (Standby State). Advance the film slowly at the front of the machine so the film rotates. The display should change to show the seal temperature, and the "RDY" (Ready State). If the error cannot be cleared, contact Pack4Shp or Pregis Help at 866-374-7877.